

MLT TWO/THREE DOLLY FORKLIFTER ADAPTER



IMPORTANT INSTRUCTIONS!

The Forklifter Adapter is only suitable for use with MLT TWO/THREE dolly. Check before use the right position of adapter and locking bolts and whether everything is tight. It is recommended to do the installation with two people.



In the first step, both the locking bolts and the screws are unscrewed so that they do not interfere with inserting the adapter.

To do this, pull the locking bolt back and turn it by approx. 45° so that it cannot jump back into its original position.



In the second step insert the forklifter adapter into the dolly from above, bevel the holder slightly and pay attention to the fixing holes in the dolly frame when positioning. If the forklifter adapter is roughly positioned, the locking bolts can be turned to their original position. If necessary move the holder back and forth a little until all bolts have snapped into place. Then tighten the screws.